



HIGH SPEED SLIDING GATE OPENER WITH BATTERY BACK-UP

Model: iS1500LV



Elsema's Eclipse® Control Card

USER MANUAL



Safety Instructions

Save these instructions for future reference.

WARNING! FAILURE TO FOLLOW THESE SAFETY AND INSTALLATION INSTRUCTIONS COULD RESULT IN INJURY OR DEATH AND/OR DAMAGE TO PROPERTY AND EQUIPMENT.

- Appropriately licensed and competent personnel only should install the automation equipment.
- The operators are designed specifically to open and close sliding gates or doors and should not be used for any other purpose.
- The gate can operate unexpectedly, so ensure nothing remains in its path.
- **Do not** operate the gate unless the user has a full view of the gate and there are no objects, person/children in the gate operation area.
- **Do not** let children play with the transmitters or any other gate control system.
- **Do not disengage** the gate opener to manual when there are children, people, objects, or vehicles within the gate's operation area. Manual release may cause uncontrolled movement.

Always incorporate the appropriate **Photo Electric Beams, Safety Bump Strip, Induction Loops** and other **safety devices** to protect both equipment and personnel. **Monitored Photoelectric Beam** must be installed and operational.

- Display all necessary signs to indicate any danger areas and automatic operation of the gate or door.
- The operators are not designed to be used in any hazardous areas or areas subject to flooding etc.
- All electrical connections and wiring must be performed with AS/NZS 3000-2018 as the guidelines.
- The manufacturer of the automation equipment is not responsible for the damage which may be caused to either the operator, gate or door and any other person or equipment when: -
 - Wrong or poor installation practices were performed.
 - No or inadequate safety devices were used.
 - Poor maintenance on the equipment.
 - Any other circumstances beyond the manufacturers control.
 - Automated gates must comply to AS/NZS 60335.1 in conjunction with AS/NZS 60335.2.103.

WARNING! ELECTRICITY CAN KILL

- **Isolate power** before attempting any maintenance.
- **Only qualified personnel** should carry out maintenance.
- **The installer** should provide all information concerning the use of the automation equipment as well as instructions regarding the manual override and maintenance procedures to the users of the system.
- Keep loose clothing and hands away from the gate whilst its being operated or could possibly be operated!
- Inspect the gate or door, along with its supporting posts and walls, to guard against potential shearing, compression, and other hazards that could lead to severe **injuries or fatalities**.
- Check the gateposts or mounting structure has the necessary strength and rigidity to support the operator and the load of the opening and closing gate motion.



Battery warning!

The product comes with wireless transmitters equipped with coin/button cell batteries, which are hazardous. Ensure these devices and their batteries are kept out of reach of children. If the battery is swallowed, it can cause severe internal burns and can lead to death in as little as 2 hours. Always secure the battery compartment. If you suspect that battery has been swallowed or inserted into any part of the body, **SEEK MEDICAL HELP IMMEDIATELY.**

Technical Features

	iS5000LV
Motor Voltage	24 Volts DC motor
Max Absorbed Power	250 Watts
Power Supply	240 Volts AC
Nominal Input Current	10 Amps
Motor Speed	367 mm/sec
Maximum Gate Weight	Up to 1,2000Kg on level ground
Duty Cycle	80% over 12 min
Operating Temperature	-20°C - +50°C
Motor Kit Weight	45Kg

Wiring Requirements

- **Single phase 240v 10A non-earth leakage protected power supply to where operator is mounted.**
- Extra Low Voltage cables from operator for access control. (Shielded cable if over 8m runs).

Installation Details

After reading the previous sections in this manual, and having checked for suitable installation, proceed as follows:-

Electrical Cabling

- A suitably rated Isolator and 240v power supply should be available near to where the gate operator is to be mounted. The following diagrams will provide measurements for the positioning of conduits and the appropriate position for mounting the operator.
- **When bringing power and control cables into the control enclosure inside the operator, please leave enough slack in the cables, in this way, the enclosure can still be lifted in order to see and work on the controls easier. To lift up control enclosure, undo wing nut on right hand side, once lifted up, re tighten the nut to keep enclosure in upwards position, once finished, undo nut, drop enclosure back down, then re tighten wing nut.**


Mechanical Installation

- Ensure gate rolls easily and has been installed in a manner where there is no excessive friction or binding occurring.
- A concrete base approximately 600mm long x 300 wide x 300mm deep should be laid where the gate operator is to be located.
- **IMPORTANT** ensure there are gate stops firmly installed in the fully open and closed positions. These stops need to be engineered and installed such that they will be strong enough to stop the gate should the limits fail at any time.
- Remove the gate operator cover and position mounting plate and operator in approximate mounting location.
- Use the rack to locate the operator the correct distance away from the gate rail (finer adjustment can be made after).
- Dynabolt or chemical anchor the bottom mounting plate to the concrete mounting pad using 12 x 100mm fixings.
- Unscrew anticlockwise the manual release knob so the drive gear free wheels.
- Fix the rack to the gate rail ensuring there is approximately 1mm - 2mm gap between the meshing of the teeth of the rack and the drive gear (no more). Move the gate by hand from one end to the other while checking that the rack is meshing correctly with the drive gear on the operator. Check also that the rack is centred around the middle of the teeth on the drive cog – tighten the mounting plate nuts.


Electrical Connections

- Connect a non earth leakage protected 10A 240v supply to Din Rail terminals labelled A & N, Connect earth to the earth Din Rail terminal.
- Conduits for power & control need to preferably come up through the base plate 'knockout'.


Plan View Layout / Conduit Position



Plan View



Back View



Side View

Quick Start Instructions



1. Place operator in correct position (Pinion wheel to be parallel to the gate and stepped out to allow for width of rack once it is mounted onto the gate frame). Mark out fixings and fix operator to the concrete pad.
2. Fix rack to the gate frame keeping 1mm-2mm clearance between the rack teeth and Pinion wheel.
3. Once the rack is fixed move the gate and sight the rack moving over the pinion wheel, check that most of the pinion wheel meshes with the rack. Make sure rack runs freely over the pinion wheel, any tight spots should be corrected by adjusting the rack height. Check the operator is firmly bolted down to the concrete pad.
4. Ensure stops are installed on the gate for the fully closed and fully open positions.
5. Connect Photo Electric Beams, Safety Bump Strip and all other safety devices as required.

Limit Switch Adjustment


The limit sensor has a + marking indicating the centre of the sensor. Adjust the sensor so that the + marking is in the centre of the magnet on the gear rack.



The 2 x limit magnets should have different marking on them. One should have a \bigcirc and the other should have a \triangle . You cannot use the limit magnets if they have the same marking. The magnets can be installed on either side (open or close). Please see the diagram below to locate the marking on the magnets.



When steel gear rack is used (or gear rack which are much slimmer), you will have to use the packing block which comes with the limit switches. Please see the diagram below.



Once the limit switches are adjusted turn the power on to the MCSv2 control card and follow on screen instructions to profile the gate. **The MCSv2 control card has been specially configured to be used with iS motor kit. For replacements please contact Elsema PTY.**


Control Inputs

- Push button** : N/O input acts as a OSC (open, stop, close) input.
- Open** : N/O input acts as a open only (swipe mode) input.
- Close** : N/O input close only input (force close) input.
- Ped Access** : Used for initiating a partial opening.
- Photo Beam (P.E)** : N/C safety input. Can be set for N/O operation if needed through menu 3.1.
PE beam operation modes can be changed through menu 4.2.

Control Outputs

- 12VDC** : Supplies regulated 12VDC at a max of 250mA, can be used for accessories such as pe cells warning devices etc, but must not exceed **250mA**.
- 24VDC** : Supplies 24VDC 1.0A regulated output, this can be used for higher power usage devices
such as induction loops. **This output is fused at 1.0 A.**
- Output 1** : N/O dry contact relay output. Do not exceed 5A load. Can be set for various functions through menu 5.1 default is Lock/Brake.
- Output 2** : Open Collector output. Can be used with Elsema’s REL 1-12 relay card.

CONTROL BOARD LAYOUT




Manual Release Instructions

Place key in door lock, turn clockwise till released and pull door open.




Turn knob anticlockwise approx. $\frac{1}{2}$ a turn to release



Gate can now be opened by hand.

To re-engage the clutch, move the gate by hand into approx. the halfway position and turn the knob clockwise until it is very tight.
If, when turning the knob clockwise and it just spins, either, try spinning it clockwise with more force to release it off the hexagonal retaining nut or hold the nut with one hand and turn the knob clockwise.



Maintenance Details



WARNING!

Failure to maintain equipment may result in injury or death and/or damage to property and equipment.

If the product is not used and maintained in accordance with instructions or recommendations listed in this User Manual, the warranty is negated.

Recommended maintenance to be performed on the operator and gate are as follows:-

Operator performs over 150 cycles a day	every 2 month
Operator performs between 20-150 cycles a day	every 6 months
Operator performs under 20 cycles a day	every 12 months

Date:

Site Name:

Site Address:

Before commencing maintenance on the operator, isolate the electrical supply to ensure operator will not run inadvertently.

- Gate rolls freely when in manual
- Gate wheels and guide rollers in good condition.....
- Gate stops are installed and in good condition, not loose.....
- Gate rack is tight & correct clearances between pinion wheel & rack.....
- Gate track is not damaged
- Gate operator mounting bolts tight.....
- No oil leaks from gearboxes.....
- Gearbox mounting bolts/nuts tight.....
- Inside operator and control box clean
- Outdoor Insect Surface Spray around operator and control box (not on electronics) ...
- All electrical connections tight
- Limit Switches operate in appropriate positions
- External safety devices work effectively / cleaned
- Electromagnetic lock, if fitted, operates correctly and is clean.....
- Wash down of control box and cover (particularly near corrosive/sea environments) ..
- General operation i.e. speed, auto close etc normal.....

Comments.....

.....

.....

Service performed by:

.....